

SOFTWARE CONFORMANCE DETAILED REPORT

COMPANY NAME	INSTITUTE OF LOGISTICS INFORMATION TECHNOLOGY (LIT)																																				
PRODUCT NAME VERSION, RELEASE	LIT RP Manager Version 2.0, Release 2.0																																				
GSRN	95011012600001442																																				
STANDARD	Reader Management (RM) Specification v1.0.1																																				
CONFORMANCE	Reader Management Conformance Requirements v1.0.1																																				
DATE	December 18, 2008																																				
DETAILS	<p>The product has completed the following mandatory requirements of this specification for XML binding:</p> <table border="1" style="width: 100%; border-collapse: collapse; margin: 10px 0;"> <thead> <tr style="background-color: #cccccc;"> <th style="text-align: left;">TCR No.</th> <th style="text-align: left;">Description</th> </tr> </thead> <tbody> <tr><td>TCR 1</td><td>get/setDescription</td></tr> <tr><td>TCR 2</td><td>get/setLocationDescription</td></tr> <tr><td>TCR 3</td><td>get/setContact</td></tr> <tr><td>TCR 4</td><td>get/serialNumber</td></tr> <tr><td>TCR 5</td><td>get/operStatus</td></tr> <tr><td>TCR 6</td><td>get/iOPort</td></tr> <tr><td>TCR 7</td><td>get/allIOPorts</td></tr> <tr><td>TCR 8</td><td>resetStatistics</td></tr> <tr><td>TCR 9</td><td>getName</td></tr> <tr><td>TCR 10</td><td>get/className</td></tr> <tr><td>TCR 11</td><td>get/setDescription</td></tr> <tr><td>TCR 12</td><td>get/setAdminStatus and get/operStatus</td></tr> <tr><td>TCR 13</td><td>get/identificationCount</td></tr> <tr><td>TCR 14</td><td>get/writeCount</td></tr> <tr><td>TCR 15</td><td>get/killCount</td></tr> <tr><td>TCR 16</td><td>get/eraseCount</td></tr> <tr><td>TCR 17</td><td>Requirement for a failed command behavior</td></tr> </tbody> </table> <p>Contact the vendor for optional features that may have been tested.</p>	TCR No.	Description	TCR 1	get/setDescription	TCR 2	get/setLocationDescription	TCR 3	get/setContact	TCR 4	get/serialNumber	TCR 5	get/operStatus	TCR 6	get/iOPort	TCR 7	get/allIOPorts	TCR 8	resetStatistics	TCR 9	getName	TCR 10	get/className	TCR 11	get/setDescription	TCR 12	get/setAdminStatus and get/operStatus	TCR 13	get/identificationCount	TCR 14	get/writeCount	TCR 15	get/killCount	TCR 16	get/eraseCount	TCR 17	Requirement for a failed command behavior
TCR No.	Description																																				
TCR 1	get/setDescription																																				
TCR 2	get/setLocationDescription																																				
TCR 3	get/setContact																																				
TCR 4	get/serialNumber																																				
TCR 5	get/operStatus																																				
TCR 6	get/iOPort																																				
TCR 7	get/allIOPorts																																				
TCR 8	resetStatistics																																				
TCR 9	getName																																				
TCR 10	get/className																																				
TCR 11	get/setDescription																																				
TCR 12	get/setAdminStatus and get/operStatus																																				
TCR 13	get/identificationCount																																				
TCR 14	get/writeCount																																				
TCR 15	get/killCount																																				
TCR 16	get/eraseCount																																				
TCR 17	Requirement for a failed command behavior																																				